




EAGLE EYE

PDA POCKET PC CLIENT



Pocket PC Client Configuration

Eagle Eye Pocket PC Client Installation: To begin the installation of the Pocket PC Client, insert the Volpe Industries product CD and install Eagle Eye Software Modules select option *Eagle Eye Pocket PC Client Installation*. Synchronize your Pocket PC first and then follow through the steps of the setup program keeping all the defaults.

To start configuring the **Eagle Eye Pocket PC Client**, run the  *Detexi* icon on your Pocket PC. A box will show up asking for your product ID # which must be retrieved from Volpe Industries. Please note the registration number and contact Volpe Industries by phone at 508-336-3898 or e-mail the registration number to techsupport@volpeindustries.com.

Once you are in Pocket PC Client, the opening screen (see Pic.1) will have a *Login* and *Setting* button that you can go to and a *Camera Setting* and *Connect* button that will be grayed out. The reason is that you can use this client in two different modes. The first mode is to access a Remote Authentication Server that will deliver all of the camera selections. The second mode is to access cameras directly from this client with the cameras defined within the Pocket PC itself.



Pic. 1

Remote Authentication Server



Pic. 2

Switching Modes



Pic. 3

Local Camera

- To switch modes, click on *Setting* button and check the *Use Local Database* box. (see Pic.2) Please note that you may have to minimize the keyboard to see this. Once you are in Local Camera mode, you may add cameras by clicking on *Camera Setting* tab. (see Pic.3)

Adding Cameras for Local Camera Mode: (see Pic.4)

- Name – enter the name for the camera
- Type – select the appropriate camera type
- Address - enter the IP address and port of the camera.
- Port – enter the port number (typically 80)
- Proxy - Select the type of camera and proxy type (typically left blank)
- Proxy Port – select the proxy port (typically left blank)
- **Click the Tools - Save button** to save the camera settings.
- Add another camera if desired

The screenshot shows a 'Camera Setup' dialog box. The title bar is blue and contains the Windows logo, the text 'Camera Setup', a speaker icon, the time '11:20', and an 'ok' button. The main content area is white and contains several input fields: 'Name' (text box with 'Camera 55'), 'Type' (dropdown menu with 'Axis 2401 2.12 or higher'), 'Address' (text box with '192.168.100.55'), 'Port' (text box with '80'), 'Proxy' (empty text box), and 'Proxy Port' (text box with '0'). At the bottom of the dialog, there is a 'Tools' bar with a keyboard icon and an arrow. Above the 'Tools' bar, there are three small buttons labeled 'Address', 'User', and 'Com'.

Pic. 4

Once the cameras have been configured, return to the main menu and click on the *Connect* button. You will now be able to access and control your Eagle Eye cameras.